




KIRNCROFT
SECURITY DOORS




CAUTION - READ FIRST: Failure to follow these installation instructions may result in injury. Care should be taken when handling the door, please ensure that the correct number of people are available during fitting and handling. It is the responsibility of the installer to ensure that hardware is fitted correctly. If painting the door, the hardware must be removed or masked. **Please note that failure to follow these instructions will invalidate the warranty.**

FIRE RATED 10-Point Locking Door - Installation

1. Stand the door up vertically and open the door. Remove the plastic packers from on top of the door and the threshold. Fit the hardware as detailed below (fig.1):
 - I. Place the plastic trim (a) over the internal handle plate (b). Insert the handle bar (c) into the handle.
 - II. Line up the handle with the handle bar hole on the door. If you require the privacy latch to be operational, insert the actuator (d) into the door. Otherwise, fold the actuator up against the inside of the handle plate.
 - III. Insert the cylinder (e) through the hole in the handle plate so that it protrudes through the external side of the door.
 - IV. Turn the thumb turn or key to engage the lock to the first locking stage and then lightly tighten the cylinder screw (f).
 - V. Place the plastic trim (g) over the external handle plate (h) and place the handle plate over the cylinder, locating the handle bar into the handle.
 - VI. Fix the handles to the door using the handle screws (i) so that they are tightened evenly, the handle plate sits flat on the door surface and all hardware is aligned correctly.
 - VII. Tighten the the cylinder screw (f) being careful not to over tighten.




5. Insert the fixing hole caps and affix the self adhesive weather seal to the door frame. (Fig.4)



2. Ensure that the aperture is square, plumb and is the correct size for the door. The opening size should be 10mm bigger than the door frame.
3. Position the bottom of the door in the aperture and then push it up so that it stands up vertically (fig.2). **Do not use the handle to lift the door.**
4. Make sure that the flange at the top of the door runs square to the top of the door frame (fig.3). If it is not square, pull the door frame over until it is square. The frame can now be welded in place or bolted through the fixing holes.

PLEASE NOTE: When the Kirncroft cylinder is attacked it is designed to engage the security lockout feature which is built in to the lock. During fitting, force should not be applied to the cylinder. To line up the handles, the cylinder and the lock, all screws should be loose or lightly tightened. The hardware can then be easily aligned.





FITTING THE HYDRAULIC CLOSER- Use the fixing screws that are already fixed into the door and frame to affix the CE/UKCA marked hydraulic closer to the door. Once installed, make sure that the door self closes with the correct amount of force so that it latches. Please refer to the manufacturers instructions for further information with regards to the power controls and assembly details.



SURFACE MOUNTING - Do not drill or screw through the door or frame as this will invalidate the fire performance of the door.



2812

Kirncroft Engineering Ltd, Wadworth Hill, Greens Lane, Burstwick,
HULL, UK HU12 9EY

J264

2812-CPR-MA7793

EN 16034:2014

KCFD1

Fire compartmentation

Resistance to fire (for fire compartmentation uses):

E: 90

E₁: NPD

E₂: NPD

EW: 90

Self closing: C

Durability of self closing: NPD



**IMPORTANT: CE MARKING
HARDWARE AND FIRE PERFORMANCE**

Please note that the handles, cylinders, locks and hinges supplied with this door are only fire rated and certified when used in conjunction with this door and frame. They are not to be sold or supplied separately as fire rated products. They have no fire performance characteristics, testing or certification when they are not fitted to this door.

Maintenance schedule

All doors	Installation	Daily	Weekly	Monthly
Visual check of overall condition	✓		✓	
Check door opens and closes smoothly	✓		✓	
Check that the door self closes and latches	✓	✓		
Check for foreign objects in the door jambs and threshold	✓	✓		
Check free operation of cylinder	✓		✓	
Check full protrusion of locking bolts	✓		✓	
Check hinges are not restricted	✓		✓	
Check smooth operation of handle	✓		✓	
When closed check that the door locks and unlocks	✓		✓	
Check handle fixing screws are tight	✓			✓
Check mortice lock fixing screws are tight	✓			✓
Check cylinder fixing screw is tight	✓			✓
Ensure hinge screws are tight	✓			✓
Ensure fixing bolts are tight	✓			✓